


Installation and operating instruction  
 Installations- und Betriebsanleitung  
 Montage- en bedieningsvoorschriften

Instructions d'installation et d'utilisation  
 Instrucciones de instalación y uso  
 Istruzioni per l'installazione e l'uso

installation date installationsdatum	instalatedatum date d'installation	fecha de instalación date of installation	location installationsort	installatieplaats place d'installation	lugar de instalación lugar de instalación



Dirt Separator  
Schlammabscheider  
Vullafscheider

Séparateur de boues  
Separatore di impurità  
Separador de lodos

UE125WJ UE150WJ UE200WJ



0-... bar  
0-... °C

Acc.PED (97/23/EC) §3.3

1

H<sub>2</sub>O

≤ 50% glycol

> 270 mm

> 270 mm

2

Rp 1/4  
Rp 1/2  
Rp 2

> 225 mm

3

4

max. 40 Nm

click

5

Pmax = 1,5 x ...bar

6

1

2

3

click

7